



USER GUIDE

Accessories for the PowerPump™:
USB-C charging cable, case insert.

PART NUMBER	PRP21
VOLTAGE	3.6V
BATTERY	3500 mAh
CONTINUOUS RUNTIME	6+ hours

Intended use

The Equalizer® PowerPump™ is a battery-powered pump and is intended exclusively for use in vacuum cups for auto glass. The use of the PowerPump™ in other applications is not permitted. Equalizer® accepts no liability if: the PowerPump™ is not used as intended, is converted or modified without authorization, components or spare parts from other manufacturers are used, is used incorrectly or by unauthorized persons, warnings, instructions and regulations in these operating instructions are not observed. **WARNING:** The appliance can be dangerous if not used as intended.

Warranty Information

The Equalizer® PowerPump™ is warrantied for three years to be free of factory defects from the date of purchase.

Equalizer® warrants this product is free from defects in materials and workmanship when used for the purpose intended, under normal conditions, and provided it receives the proper care and maintenance as described in this User Guide.

This warranty is good only for authentic, original, legitimate tools manufactured by Equalizer® and sold through Authorized Distributors or from Equalizer®.

Warranty does not cover:

- Abuse, misuse, normal wear and tear to tool or accessories.
- Damage due to repairs being made by unauthorized persons.

Safety instructions

Observe the following rules to achieve the highest possible level of safety when using the PowerPump™ :

- Follow the instructions in this operating manual.
- Test the function of the PowerPump™ and vacuum cup before each use.
- Do not use the PowerPump™ and vacuum cup if they are damaged.
- Switch off the PowerPump™ when not in use.
- Protect the PowerPump™ from strong shocks, impacts, moisture, heat and direct sunlight.
- The PowerPump™ is not waterproof.
- Keep both the cup and PowerPump™ clean and dry.

Operating instructions

Charge the PowerPump™ before using.

Remove the existing plunger from your suction cup handle and insert the PowerPump™.

Press the power button to turn ON.

Place suction cup on the glass and wait until the cup is securely attached before lifting.

The PowerPump™ suction will run constantly while powered on.

Press the power button to turn OFF when finished.

Battery Status Light Indicator



Battery is charged



Battery needs to be charged

Charge the PowerPump™ with the provided USB-C cable